



## DELTA 5X XENON BACK-UP LIGHT BAR With 4 Built-in Xenon Flood Lights for HUMMER H2 P/N 01-01-9065-5X

### INSTALLATION INSTRUCTION

1. Slide your new 5X Light Bar over factory roof rails.
2. Run wiring harness through the rear of the fender well and mount the relay in the back of the vehicle.
3. Ground the relay and the light bar (black wire leads) to the metal surface with self-tapping screws.
4. Remove fuse from the fuse holder and connect the red wire lead to the positive (+) side of the battery.
5. Run yellow wire lead from the relay alongside the driver's side of the floor and through the hole in the firewall on the driver's side of the H2.
6. Continue with the yellow wire along existing wires inside engine compartment until you reach the red fused wire connected to the battery.
7. Connect the yellow wire lead to the red fused wire using the supplied butt connector.
8. Remove plastic cover from the roof. (clearance light-driver side) Feed 3 wires (2 yellow, 1 black) from the harness through the existing hole inside the clearance light.
9. Lock in 3 terminated wires leading from the harness into a 3-hole connector. Push black terminated wire into the inside round hole of the plastic waterproof connector and follow the same with yellow wires into the outside round holes.
10. Connect harness to the backup light bar.
11. Using snap-lock connector, splice the blue wire leading from the relay to the factory wire backup wire (purple w/black stripe) going to the tail lights.  
Replace the fuse and test lights. Your DELTA Backup Lights will be activated with the shift in the reverse gear. **BACKUP WITH CONFIDENCE!**



#### CONTENTS:

- (1) Backup Bar w/4 Xenon Flood lights
- (1) Harness
- (1) Fuse Holder w/ 20A fuse
- (1) Snap-lock connector
- (1) plastic Connector
- (6) wire ties
- (2) screws