



## INSTALLATION OF DELTA LED BLINKER LIGHTS P/N 01-6575-50



1) DECIDE WHERE YOU WANT TO PLACE YOUR LED SIGNAL LIGHTS. POPULAR LOCATIONS ARE ON THE FRONT FENDERS OR THE MIRROR HOUSINGS.

2) APPLY MASKING TAPE TO THE AREA YOU WISH TO ADD THE SIGNAL LIGHTS AND MARK YOUR SERIES OF  $\frac{3}{4}$  INCH HOLES TO DRILL.

3) DEPENDING ON WHAT KIND OF MATERIAL YOU ARE DRILLING INTO, USE A  $\frac{3}{4}$  INCH HOLE SAW AND MAKE YOUR HOLES. (NOTE:  $\frac{3}{4}$  IS THE HOLE SIZE FOR THE RUBBER GROMMET)

4) SIMPLY WORK THE GROMMET INTO THE HOLES YOU JUST DRILLED. IT IS EASIER TO REMOVE THE LIGHT FROM THE GROMMET AND INSTALL THE GROMMET SEPERATLY THEN SLIP THE LIGHT IN.

5) NEXT, EXTEND THE WIRE LEADS, WITH THE SUPPLIED WIRE, AND RUN YOUR RED POSITIVE TO 12V SIGNAL LEAD AND THE BLACK TO A GOOD GROUND SOURCE.

6) DOUBLE CHECK ALL CONNECTIONS AND TEST YOUR LIGHTS.

